





Installation and Maintenance Manual
ACO Access Covers - SERVOKAT GD





- ENG** Installation Manual
- GER** Installationsanleitung
- FRA** Instructions d´installation
- ESP** Manual De Instalación
- POR** Manual de Instalação
- ITA** Manuale d´installazione
- NLD** Installatiehandleiding
- CZE** Instalační manuál
- RUS** Инструкция По Установке
- SWE** Installationsanvisning
- NOR** Installasjons Manual
- FIN** Asennusohje
- DAN** Installationsvejledning
- EST** Paigaldusjuhend
- LAV** Uzstādīšanas instrukcija
- LIT** Montavimo instrukcija
- POL** Instrukcja montażu
- BUL** Инструкции за инсталация
- HUN** Beépítési útmutató
- RUM** Instrucțiuni de instalare
- HRV** Upute za ugradnju
- SLV** Navodila za vgradnjo
- SRP** Preporuka za ugradnju
- TUR** ACO Mühahale Kapakları

















A




B















$F \leq 25 \text{ kg}$ ✓
 $F > 25 \text{ kg}$ ✗



**ACO. creating
the future of drainage**

www.aco-accesscovers.com



Article Number: **NM11560** ACO Access Covers - SERVOKAT GD/EN/06/19